

EOS ACCESSORIES COMPATIBLTY CHART

EOS LINE UP	DIGITAL SINGLE LENS REFLEX										MIRRORLESS					
EOS ACCESSORIES	EOS 3000D	EOS 1500D	EOS 200D II	EOS 850D	EOS 80D	EOS 90D	EOS 6D Mark II	EOS 5D Mark IV	EOS 1D X Mark III	EOS M50 Mark II	EOS M6 Mark II	EOS RP	EOS R	EOS R6	EOS R5	EOS C70
Battery Pack	LP-E10	LP-E10	LP-E17	LP-E17	LP-E6N/LP-E6NH	LP-E6N/LP-E6NH	LP-E6N/LP-E6NH	LP-E6N/LP-E6NH	LP-E19	LP-E12	LP-E17	LP-E17	LP-E6N/LP-E6NH	LP-E6N/LP-E6NH	LP-E6N/LP-E6NH	BP A30 / A60
Battery Charger	LC-E10E	LC-E10E	LC-E17E	LC-E17E	LC-E6E	LC-E6E	LC-E6E	LC-E6E	LC-E19	LC-E12E	LC-E17E	LC-E17E	LC-E6E	LC-E6E	LC-E6E	CG A20
Battery Grip	N/A	N/A	N/A	N/A	BG-E14	BG-E14	BG-E21	BG-E20	N/A	N/A	N/A	N/A	BG-E22	BG-R10	BG-R10	N/A
ACK Kit --AC Adapter --DC Coupler	ACK-E10 • CA-PS700 • DR-E10	ACK-E10 • CA-PS700 • DR-E10	ACK-E18 • AC-E6N • DR-E18	ACK-E18 • AC-E6N • DR-E18	ACK-E6 • AC-E6N • DR-E6	ACK-E6 • AC-E6N • DR-E6	ACK-E6 • AC-E6N • DR-E6	ACK-E6 • AC-E6N • DR-E6	ACK-E19 • AC-E19 • DR-E19	• CA-PS700 • DR-E12	• CA-PS700 • DR-E17	ACK-E18 • AC-E6N • DR-E18	ACK-E6 • AC-E6N • DR-E6	ACK-E6 • AC-E6N • DR-E6	ACK-E6 • AC-E6N • DR-E6	N/A • CA CP 200L • N/A
Remote Switch	RS-60E3	RS-60E3	RS-60E3/BR-E1	RS-60E3/BR-E1	RS-60E3/RC-6	RS-60E3/RC-6/BR-E1	RS-80N3/RC-6/BR-E1	RS-80N3/RC-6	RS-80N3/RC-6	BR-E1	RS-60E3/BR-E1	RS-60E3/BR-E1	RS-60E3/BR-E1	RS-60E3/RC-6/BR-E1	RS-60E3/RC-6/BR-E1	RCV 100
Microphone	N/A	N/A	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	DM-E1/DM-E100	Dual Mini XLR + 3.5mm

LENSES ACCESSORIES COMPATIBILITY CHART

LENS LINE UP	LENS HOOD	LENS FILTER	LENS CAP	LENS LINE UP	LENS HOOD	LENS FILTER	LENS CAP	LENS LINE UP	LENS HOOD	LENS FILTER	LENS CAP
ULTRA WIDE/WIDE ANGLE LENS				WIDE ZOOM/STANDARD ZOOM LENS				EF-M LENS [FOR EOS M SERIES CAMERA]			
EF8-15mm f/4L Fisheye USM	EW-77	N/A	Exclusive	EF11-24mm f/4L USM	Built in	N/A	Exclusive	EF-M22mm f/2 STM	EW-43	43mm	E-43
EF14mm f/2.8L II USM	Built-in	N/A	Exclusive	EF16-35mm f/2.8L III USM	EW-88D	82mm	E-82 II	EF-M28mm f/3.5 Macro IS STM	ES-22	43mm	EF-M28
EF24mm f/1.4L II USM	EW-83K	77mm	E-77 II	EF16-35mm f/4L IS USM	EW-82	77mm	E-77 II	EF-M32mm f/1.4 STM	ES-60	43mm	E-43
EF24mm f/2.8 IS USM	EW-65B	58mm	E-58 II	EF17-40mm f/4L USM	EW-83E	77mm	E-77 II	EF-M15-45mm f/3.5-6.3 IS STM	EW-53	49mm	E-49
EF35mm f/1.4L II USM	EW-77B	72mm	E-72 II	EF24-70mm f/2.8L II USM	EW-88C	82mm	E-82 II	EF-M18-150mm f/3.5-6.3 IS STM	EW-60F	55mm	E-55
EF35mm f/2 IS USM	EW-72	67mm	E-67 II	EF24-105mm f/4L IS II USM	EW-83M	77mm	E-77 II	EF-M55-200mm f/4.5-6.3 IS STM	ET-54B	52mm	E-52 II
EF40mm f/2.8 STM	ES-52	52mm	E-52 II	EF24-105mm f/3.5-5.6 IS STM	EW-83M	77mm	E-77 II	RF LENS [FOR EOS R SERIES CAMERA]			
STANDARD/MEDIUM TELEPHOTO LENS				TELEPHOTO ZOOM LENS				RF15-35mm f/2.8L IS USM	EW-88F	82mm	E-82 II
EF50mm f/1.2L USM	ES-78	72mm	E-72 II	EF70-200mm f/2.8L IS III USM	ET-87	77mm	E-77 II	RF35mm f/1.8 Macro IS STM	EW-52	52mm	E-52 II
EF50mm f/1.4 USM	ES-71 II	58mm	E-58 II	EF70-200mm f/2.8L USM	ET-83 II	77mm	E-77 II	RF24-70mm f/2.8L IS USM	EW-88E	82mm	E-82 II
EF50mm f/1.8 STM	ES-68	49mm	E-49	EF70-200mm f/4L IS II USM	ET-78B	72mm	E-72 II	RF28-70mm f/2L USM	EW-103	95mm	E-95
EF85mm f/1.2L II USM	ES-79 II	72mm	E-72 II	EF70-300mm f/4-5.6L IS USM	ET-73B	67mm	E-67 II	RF50mm f/1.2L USM	ES-83	77mm	E-77 II
EF85mm f/1.8 USM	ET-65 III	58mm	E-58 II	EF70-300mm f/4-5.6 IS II USM	ET-74B	67mm	E-67 II	RF50mm f/1.8 STM	ES-65B	43mm	E-43
EF85mm f/1.4L IS USM	ET-83E	77mm	E-77 II	EF75-300mm f/4-5.6 III	ET-60	58mm	E-58 II	RF85mm f/1.2L USM	ET-89	82mm	E-82 II
TELEPHOTO/SUPER TELEPHOTO LENS				EF100-400mm f/4.5-5.6L IS II USM	ET-83D	77mm	E-77 II	RF85mm f/1.2L USM DS	ET-89	82mm	E-82 II
EF135mm f/2L USM	ET-78 II	72mm	E-72 II	EF-S LENS				RF85mm f/2 Macro IS STM	ET-77	67mm	E-67 II
EF200mm f/2L IS USM	ET-120B	52mm Drop-in	E-145B	EF-S35mm f/2.8 Macro IS STM	ES-27	49mm	EF-S35	RF24-105mm f/4L IS USM	EW-83N	77mm	E-77 II
EF300mm f/4L IS USM	Built-in	77mm	E-77 II	EF-S10-18mm f/4.5-5.6 IS STM	EW-73C	67mm	E-67 II	RF24-240mm f/4-6.3 IS USM	EW-78F	72mm	E-72 II
EF400mm f/2.8L IS III USM	ET-155 (WIII)/ET-155B	52mm Drop-in	E-180E	EF-S10-22mm f/3.5-4.5 USM	EW-83E	77mm	E-77 II	RF70-200mm f/2.8L IS USM	ET-83F (WIII)	77mm	E-77 II
EF500mm f/4L IS II USM	ET-138 (WII)	52mm Drop-in	E-163B	EF-S17-55mm f/2.8 IS USM	EW-83J	77mm	E-77 II	RF70-200mm f/4L IS USM	ET-83G (WIII)	77mm	E-77 II
EF600mm f/4L IS III USM	ET-160 (WIII)/ET-160B	52mm Drop-in	E-185C	EF-S18-55mm f/4-5.6 IS STM	EW-63C	58mm	E-58 II	RF100-500mm f/4.5-7.1L IS USM	ET-83F (WIII)	77mm	E-77 II
EF800mm f/5.6L IS USM	ET-155	52mm Drop-in	E-180C	EF-S18-135mm f/3.5-5.6 IS USM	EW-73D	67mm	E-67 II	RF600mm f/11 IS STM	ET-88B	82mm	E-82 II
MACRO LENS				EF-S18-135mm f/3.5-5.6 IS STM	EW-73B	67mm	E-67 II	RF800mm f/11 IS STM	ET-101	95mm	E-95
EF100mm f/2.8L Macro IS USM	ET-73	67mm	E-67 II	EF-S18-200mm f/3.5-5.6 IS	EW-78D	72mm	E-72 II	EXTENDERS			
EF100mm f/2.8 Macro USM	ET-67	58mm	E-58 II	EF-S55-250mm f/4-5.6 IS STM	ET-63	58mm	E-58 II	Extender EF 1.4x III	None	None	None
EF180mm f/3.5L Macro USM	ET-78 II	72mm	E-72 II	EF-S55-250mm f/4-5.6 IS II	ET-60	58mm	E-58 II	Extender EF 2x III	None	None	None
MP-E65mm f/2.8 1-5x Macro Photo	MP-E65	58mm	E-58 II								
TILT & SHIFT LENS											
TS-E17mm f/4L	None	None	Lens Cap 17								
TS-E24mm f/3.5L II	EW-88B	82mm	E-82 II								
TS-E50mm f/2.8L Macro	ES-84	77mm	E-77 II								
TS-E90mm f/2.8L Macro	ES-84	77mm	E-77 II								
TS-E135mm f/4L Macro	ET-88	82mm	E-82 II								

Accessories compatibility of EOS Cameras/Lenses are a subject to change without prior notification